



MINISTRY OF THE ENVIRONMENT  
LABORATORY SERVICES BRANCH

A handwritten signature in the top right corner of the page.

# **A GUIDE TO AIR FILTER (HI-VOL AND PM10) SAMPLING AND SUBMISSION**

Kirsten Burling, Jane Thrush, George Kanert  
Laboratory Services Branch

MOE  
GUI  
AJGW

Issue 1: November, 2000

c.1  
a aa

### Copyright Provisions and Restrictions on Copying:

This Ontario Ministry of the Environment work is protected by Crown copyright (unless otherwise indicated), which is held by the Queen's Printer for Ontario. It may be reproduced for non-commercial purposes if credit is given and Crown copyright is acknowledged.

It may not be reproduced, in all or in part, for any commercial purpose except under a licence from the Queen's Printer for Ontario.

For information on reproducing Government of Ontario works, please contact ServiceOntario Publications at [copyright@ontario.ca](mailto:copyright@ontario.ca)

## Acknowledgments

The authors would like to thank the following people for their review of this manual and their valuable comments:

Gerald Diamond  
Frank Dobroff  
Leighton Horner  
Don Racette  
Fred Seymour

## TABLE OF CONTENTS

1	INTRODUCTION .....	1
1.1	TSP .....	1
1.2	PM10 .....	1
2	SETTING UP A NEW SAMPLING STATION .....	2
3	ORDERING BLANK FILTERS .....	2
4	RETURNING UNUSED BLANK FILTERS .....	3
5	SAMPLER .....	3
5.1	MAINTENANCE OF HIGH-VOLUME SAMPLERS .....	3
6	EXPOSING FILTERS .....	4
7	EXPOSED FILTERS .....	4
8	SAMPLE AND SAMPLE ENVELOPE .....	5
9	INVALIDATION OF SAMPLES .....	6
9.1	SAMPLE INVALID FOR ALL ANALYSES .....	6
9.2	SAMPLE INVALID FOR PARTICULATE ANALYSIS ONLY .....	7
10	SUBMISSION FORM .....	7
10.1	SUBMISSION FORM HEADER .....	8
10.2	SUBMISSION FORM BODY .....	9
11	NO SAMPLE .....	10
12	SUBMITTING SAMPLES .....	10
13	LIMS REMARK CODES AND VALUE QUALIFIERS .....	11
13.1	REMARK CODES .....	11
13.2	VALUE QUALIFIERS .....	11
	GLOSSARY .....	13
	APPENDIX A - TYPES OF EXPOSED FILTERS .....	A-1
	APPENDIX B - SAMPLE ENVELOPES .....	B-1
	APPENDIX C - SUBMISSION FORMS .....	C-1
	APPENDIX D - LIMS PARENT PRODUCTS/PRODUCTS .....	D-1

AJGW



# A GUIDE TO AIR FILTER (HI-VOL AND PM10) SAMPLING AND SUBMISSION

## 1 INTRODUCTION

Suspended particulate matter in the atmosphere results both from natural sources and anthropogenic activity. Natural sources include wind blown dust, volcanic ash, pollen, smoke and fly ash from forest fires. Man's activities have greatly increased average levels of suspended particulate, with the highest concentrations found in industrialized downtown areas, as well as near expressways and, to a lesser extent, solid waste incinerators. Residential locations report relatively low levels of air particulate. Rural areas also follow this pattern except during tilling when conditions are dry and windy.

Suspended particulates in the atmosphere can cause: a reduction in visibility; alterations in sky illumination due to changes in the light scattering pattern; a decrease in the amount of solar radiation reaching the earth's surface; an increase in damage to vegetation and property; and an increase in physiological reactions including allergies and irritation to the respiratory tract. Health agencies have determined that particles of less than  $5\mu\text{m}$  in diameter can enter the respiratory tract and cause health problems.

The current accepted Ontario ambient air quality criterion (AAQC) for Total Suspended Particulate (TSP) on high volume (Hi-vol) filters is  $120\mu\text{g}/\text{m}^3$  for a 24-hour period and an annual geometric mean of  $60\mu\text{g}/\text{m}^3$ . The current Ontario interim AAQC for inhaleable fine particles less than  $10\mu\text{m}$  (PM10) is  $50\mu\text{g}/\text{m}^3$  for 24-hours.

### 1.1 TSP

- The method commonly used for determining the quantity of total suspended particulate matter in the atmosphere uses a Hi-vol sampler that draws air through a glass fiber filter. Samples are under a shelter which excludes precipitation and particulate larger than about  $100\mu\text{m}$ .
- The glass fiber filters  $20.3 \times 25.4\text{ cm}$  (8" X 10") in size have a collection efficiency of at least 99% for particles of  $0.3\mu\text{m}$  in diameter. Particles with diameters exceeding  $100\mu\text{m}$  remain on the filter surface whereas particles with diameters down to  $0.1\mu\text{m}$  are collected on the glass fibers in the filters.
- Some inorganic tests are incompatible with the glass-fibre matrix. These include: Al, Ba, B, Ca, Na, K, Si, and F.

### 1.2 PM10

- Inhaleable particulate having an aerodynamic diameter of less than  $10\mu\text{m}$  is collected by placing a size selective inlet (a round, engineered top) on a high-volume sampler, and employing quartz-fibre filters  $20.3 \times 25.4\text{ cm}$  (8" X 10") in size.
- Some inorganic tests are incompatible with the quartz-fibre matrix. These include: Al, Ba, B, Na, Si and F.

## 2 SETTING UP A NEW SAMPLING STATION

A new routine sampling station must fit in with the allotted laboratory workload for that region. This is the responsibility of the Technical Support Manager. Changes should be requested through the Workload Coordinator for Operations Division.

A complete set of information must be submitted to the Laboratory Services Branch (LSB) Inorganic Air Unit, so that a new submission form can be generated. This information includes:

- Client contact, client code, ministry, branch, office address, city/town, postal code, telephone and fax numbers,
- Sampler's name and telephone number,
- Program code, priority, station ID, sample location, municipality, matrix, sampling start date and sampling schedule (e.g. 1, 3, or 6-day cycle) and Laboratory Information Management System (LIMS) product(s).

## 3 ORDERING BLANK FILTERS

**Hi-vol air filters are ordered from the contract laboratory:**

Seprotech Laboratories  
2378 Holly Lane  
Ottawa, ON K1V 7P1  
Attention: Dave Lambert

Telephone (613) 523-1641  
Fax (613) 731-0851  
E-mail: dlambert@Seprotech.com

**PM-10 filters are ordered from LSB:**

Ministry of the Environment  
Laboratory Services Branch  
Physical Chemistry & Litigation Services Section  
Inorganic Air Unit  
125 Resources Road  
Etobicoke, ON M9P 3V6  
Attention: Kirsten Burling

Telephone (416) 235-5849  
Fax (416) 235-6113  
E-mail: burlinki@ene.gov.on.ca

Alternate:  
Customer Services Help Desk

Telephone (416) 235-6030  
Fax (416) 235-6141

Blank filters should be ordered three weeks ahead of the required time. The order should include :

- the name and address of the person to whom the filters will be sent.
- the type of filter - PM10 or Hi-vol.
- the station number.
- the last filter number received, unless it is a new station.
- the number of filters required (if other than the usual 25).
- the date by which the filters should arrive at the requesting office.

Blank filters are stamped with an eight-digit identification number on the top left and the bottom right corner of the filter. The numbers are placed on the screen-pressed surface which is the one with the least fibre surface area.

When the exposed filter is returned to the laboratory, its eight-digit identification number is used to match the filter to its tare weight. The sample is then conditioned and weighed. The two weights (unexposed and exposed) are then used to calculate the particulate loading.

The filter batch (lot number) is stamped in the bottom left corner of the screen-pressed surface of each filter. In this way, unused filters which are returned to the laboratory are identified as to their batch and thus filters with the same station-filter number may be distinguished from one another (these numbers repeat after every 999 filters).

#### **4 RETURNING UNUSED BLANK FILTERS**

Unused filters from terminated stations, etc., should be returned to the Inorganic Air Unit, Laboratory Services Branch. They should be returned in the original box in which they were sent out as it has the station, filter and batch numbers on it. If a substitute box is used, then a note should be included with the station number, the batch number, the first and last filter numbers being returned and the reason for the return (e.g. station terminated or wrong station stamped on filter. Do not mix batches or stations together. These filters may then be restamped and sent out again.

#### **5 SAMPLER**

Samples are collected by means of a high-flow-rate sampler capable of drawing air at a rate of 1.3 m<sup>3</sup>/minute. The sampler is calibrated at 1.13 m<sup>3</sup>/minute (40 cfm) and usually runs for a 24-hour period using a flow controller.

##### **5.1 MAINTENANCE OF HIGH-VOLUME SAMPLERS**

Certain maintenance procedures help ensure problem-free samples:

- a) Motor brushes should be replaced periodically. This is done after approximately 400 to 500 hours of operation at 115 volts. A "Step-down" transformer can be used to increase brush life.
- b) Motor gaskets are cleaned as needed and replaced when worn.
- c) The flow-measuring device and tubing are inspected visually each time a filter is changed and are cleaned or replaced as needed.
- d) The faceplate gasket is replaced when worn or cracked through. (Exposed filters may show signs of particulate seepage under the gasket before the gasket appears to be worn).
- e) The inside of the sampler (shelter and roof) should be cleaned:
  - The Hi-vol sampler, annually or as needed with a coarse wire brush.
  - The PM10 sampler, after every 4<sup>th</sup> sampling day or more frequently, as required.
- f) The sampler must be visually clean. With each use, it is inspected for bird and wasp nests, spider webs and insects and droppings. If found, they must be removed.
- g) The filter-holder, especially the gasket and horn, is cleaned of dirt each time the filter is changed.
- h) The filter-holder housing is inspected for leaks each time a filter is changed.
- i) The shelter is inspected for leaks whenever a new head is used.

## 6 EXPOSING FILTERS

If a new, unused filter is damaged, such that it may compromise the collection of suspended particulate, the filter must not be used. Small imperfections along the margin of the filter will not affect particulate collection as long as the filter is centered in the filter holder.

- Care must be taken not to contaminate the filter. Hands and filter holder (particularly the faceplate gasket) should be clean.
- The filter is to be installed with the side having the greater fibre surface area facing upward. The surface of this side looks less compacted and more irregular. The filter identification numbers should be facing downward. They should be on the side which has the flattened, screen-pressed look to it. The proper side should be exposed regardless of which side has the numbers.
- Filters should be exposed in numerical order.
- The filter is centered in the holder so that the unexposed margin is even all the way around. If not centered, when the filter is folded, some of the particulate from one side will be transferred to the margin of the other side.

The faceplate gasket should form a seal around the filter and be seated tightly enough that particulate cannot seep underneath. The gasket should be free of cracks through which particulate may escape.

## 7 EXPOSED FILTERS

During the time that a filter sits in the sampler, circumstances may occur which could cause either a gain or a loss in the mass of the sample. Since the suspended particulate tests concern sample mass, what happens to the filter could be critical to the integrity of the result.

Filters must be handled carefully to avoid tearing, contamination or loss of particulate. Before a filter is removed from the sampler and, as it is being removed from the sampler, the filter is inspected for tears, scrapes, perforations and extraneous material. The latter should be removed if this can be done without disturbing the integrity of the filter and the particulate thereon.

Complete sample invalidation should be done by field staff before a sample is submitted. Laboratory staff cannot invalidate a filter sample without first consulting the region. A sample may however, be invalidated for a particular test by either field or laboratory staff. There are 3 ways in which a filter may be deleteriously affected: by a **loss** of mass, a **gain** of mass, or a **loss and gain** of mass. The severity of these conditions determine whether or not a filter is invalidated.

See Appendix A, for various examples of the above conditions.

## SAMPLE AND SAMPLE ENVELOPE

The sample is carefully removed from the cassette or filter holder, folded in half across the middle of the longer 10 inch (25.4 cm.) side so that the particulate-covered surface is folded against itself.

PM10 filters are more delicate than Hi-vol filters. The filter is folded by placing it between the lines on the smooth cardstock folder, provided by the lab. It is held in place as the folder is folded. Pressure exerted by the fingers along the fold of the folder will press a fold into the filter.

Tears or scrapes occurring as the filter is being removed from the sampler as well as those having occurred during sampling, should be noted in the comments area on the sample envelope. Torn off pieces should be placed inside the folded filter, near the outer edge of the shorter ends.

The folded filter should be placed into the sample envelope with the fold on the left and the open side to the right. See Appendix B, Figure 1. (Sample envelopes are stored at the laboratory, with the left side down. In this way, any loose, dislodged particulate will be caught in the fold of the filter.) The PM10 filter is left in the folder and both are placed with the fold on the left into the sample envelope for return to the laboratory.

The following information is **mandatory** for LSB and is entered onto each sample envelope. See Appendix B:

- STATION -** The station number is the sampling location. Normally, this is the first 5 digits of the 8-digit number stamped on the top left and bottom right corner of the filter (if the filter is exposed at a station other than the one for which it was stamped, the entire 8-digit number **must be** put on the FILTER No. line. Print the number of the station at which the filter was exposed, on the STATION number line)
- DATE -** The sampling date is the day (or the first day of a series of days) that the filter was exposed.
- The format is DD-MMM-YYYY (e.g. 13-OCT-1999).
- FILTER No. -** This is the last 3 digits of the 8-digit number that is stamped on top left and bottom right corner of the filter, (if the filter is exposed at a station other than the one for which it was stamped, the entire 8-digit number should be put in the FILTER No. space. Print the number of the station at which the filter was exposed, on the STATION number line). See Appendix B, Figure 2.
- TYPE -** For Hi-vol enter HG (Hi-vol Glass); for PM10 enter QU (Quartz).
- BATCH No. -** This is the number on the bottom left of the filter.
- TOTAL VOLUME -** This is the actual calculated air volume. (See next heading, COMMENTS.)
- COMMENTS -** If a sample is invalid, the word INVALID is printed on this line and the air volume is not reported.

Other information may also be entered onto the envelope. Comments regarding unusual sampling conditions should be noted. This information may be important during data evaluation.

Avoid writing comments on the bottom right corner of the sample envelope as laboratory sample numbers will be applied to this area.

## **9 INVALIDATION OF SAMPLES**

Comments relating to validity of the sample should be entered for the benefit of both laboratory staff and Regional Analyst.

Questionable samples may be returned to the Regional Analyst.

### **9.1 SAMPLE INVALID FOR ALL ANALYSES**

Samples are invalidated under the following circumstances:

- (1) If site access or other circumstances prevent the sample from being taken.
- (2) If vandalism is suspected.
- (3) If field equipment such as the sampler motor or the flow controller fail to function properly.
- (4) If a perforation or tear of any size occurs within the particulate collection area during sampling.
- (5) If a leak in the gasket seal occurs during sampling and evidence of the leak extends to the edge of the filter.
- (6) If bird droppings contaminate more than 5% (4 square inches) of the exposed filter.
- (7) If two filters are exposed simultaneously in the same sampler.
- (8) If a filter is exposed on an unscheduled sample day.

If a sample which has not been invalidated is suspected of being invalid, the sample should be sent for final validity determination to the Regional Analyst for the region which generated the sample.

If a sample is invalid:

- On the sample envelope, "INVALID" is printed in the comments area and the air volume is left blank. See Appendix B, Figure 1.
- On the submission form, the air volume box should contain the word "INVALID". The product for any invalid filter, is TSPINV3288. This product is entered on the submission sheet instead of the normal product(s). See Appendix C, Figure 1 and Appendix D, Table D-3.

## 9.2 SAMPLE INVALID FOR PARTICULATE ANALYSIS ONLY (TSP2009 or TSP3288 or IP3288)

Samples may be invalid for the analysis of total suspended or inhaleable particulate and still be valid for the analysis of other parameters.

- There are two product codes in LIMS for Hi-vol samples: TSP2009 for the samples going to the private laboratory and TSP3288 for the samples going to the MOE LSB analyst (special cases).
- There is one PM10 LIMS code: IP3288 sends the quartz PM-10 filters to the MOE LSB analyst.

If a sample is invalidated for the particulate loading only, then, in the product column of the submission form, enter either **-TSP2009** or **-TSP3288** or **-IP3288** (depending on which matrix/analysis and where the sample is going for analysis) along with the normal product, (e.g. HVT -TSP2009 or QUARTZ -IP3288). See Appendix C, Figure 4. This will notify data entry personnel to delete the particulate test from the parent product. The other tests will be entered as usual. The following conditions may invalidate the sample for particulate loading only:

- (1) If there has been a significant loss of particulate material due to a tear or a scrape which occurred **after** sampling. For a Hi-vol sample, this would be approximately 0.045 grams of material. For a PM10 sample this would be about 0.022 grams of lost particulate.
- (2) If a piece of filter tore off and was lost after the blank filter was shipped from the laboratory and the missing piece is about equal to 1 in<sup>2</sup> (2.5 cm<sup>2</sup>) for Hi-vol or 0.5 in<sup>2</sup> (1.25 cm<sup>2</sup>) for PM10.
- (3) If bird droppings contaminate less than 5% (4 square inches) of the filter, the filter **may** still be valid for other tests. **It is mandatory that the contaminated part of the filter not to be used is clearly indicated on the envelope.**
- (4) If non-target material such as insects or plant matter adhered to the filter, then the material should be removed prior to submitting the sample to the laboratory. This is most easily done with pointed forceps. If this material was large and is estimated to have interfered with the collection of particulate directly onto the filter, then the sample should be invalidated for particulate loading.

The Product code TSPINV3288 is assigned to an invalid sample for tracking purposes.

## 10 SUBMISSION FORM

See Appendix C for examples of submission forms.

Submission forms are generated by LSB. They are bar-coded to facilitate data entry. The preprinted information must be verified as being correct. If there are errors or changes, the incorrect information is to be corrected on the submission sheet and e-mailed to the Laboratory Services Branch contact.



## 10.1 SUBMISSION FORM HEADER

**Submission Number** - This is normally left blank by the field staff. Laboratory staff will place a bar-coded label on this box.

**Prelog Number** - This is currently unused. Eventually, each sample will be assigned a LIMS prelog sample number. This number will become the submission number when the filters are submitted for analyses. The prelog number will begin with the letter P and will be changed to a C (for Central Laboratory) when the sample is returned and received back into LIMS at the lab. The P designated number is to be used as a submission number by clients.

**Client Contact** - This is the person to whom the final data will be sent (usually the data analyst).

**Client ID** - This is the 5-digit LIMS code for the client contact.

**Program Code** - This is the 9-digit code determined by the Regional Tech Support Manager. It is a string of 4 codes. All codes begin with 13011.

- 13 indicates the program - MOE Operations Division.
- 011 indicates the study - air (industrial, commercial, private or networks).
- the next two digits indicate the project, e.g. 41 - Southwestern Region, London District.
- last two digits indicate the activity:
  - 01 - AQ (Air Quality Index) & API (Air Pollution Index) stations
  - 02 - point source monitoring
  - 03 - ambient monitoring
  - 04 - studies
  - 05 - complaints & notifications

**Priority** - This is the assigned urgency of analysis. Priorities other than NN require a request from the appropriate Director to the LSB Director.

- NN ROUTINE
- EM EMERGENCY - HEALTH RISK (ASAP)
- PR PRIORITY - RUSH (7 DAYS)
- RE REGULATION (30 DAY TURNAROUND TIME)
- CC POTENTIAL LITIGATION (COURT CASE)

**Page** - The first page of the submission is labeled Page 1. For the 3 day cycle the pages are labeled 1 of 2 and 2 of 2.

**Sample Location / Municipality** - This is the station name (which includes a street name or intersection), as well as the municipal jurisdiction (City/Town), (e.g. Gertrude & Depew /Hamilton).

**Date Submitted** - This is the date that the samples are sent or taken to the laboratory for analysis.

**Ministry / Branch / Office** - This is the address of the client contact to whom the final reports will be sent. Usually, this is the Ministry of the Environment / the region or district / the street address (e.g. Ministry of the Environment, Southwestern Region, 659 Exeter Road South, 2<sup>nd</sup> floor).

**Telephone Number** - This is the telephone number of the client contact.

**Fax Number** - This is the fax number for the client contact.



**City / Town** - This is for the mailing address of the client contact.

**Postal Code** - This is for the mailing address of the client contact.

**Sampled By - Name** - this is the name of the sampler(s) responsible for producing the samples being submitted.

- **Telephone Number** - This is the telephone number of the sampler.

**Station ID** - this is the unique, 5-digit, station, location, identification number.

**Matrix** -Sample matrix is one of the following: AG - Air-filter, Glass-fibre; AQ - Air-filter, Quartz-fibre; AO - Air, Other filters and puff. ( This guide deals with only AG and AQ).

**Sample Reception / Data Entry** - This area is to be left blank for laboratory staff.

## 10.2 SUBMISSION FORM BODY

**Lab Sample Number** - These two columns are left blank for laboratory staff.

**Sample Number** - This is the identification number assigned to a sample. Laboratory staff will place a bar-coded label in this box and a similar label on the sample envelope just above the bottom fold on the right side.

**MOE\*LIMS** - This number indicates the year, the sample matrix, the week the sample was entered into LIMS and the number of samples of that matrix received to date for the week.

**Sample Date** - This is the exposure date for the filter. It is the first day if there was more than one day of exposure. The format is DD-MMM-YYYY (e.g. 03-OCT-1999).

**Filter Number** - This is the running number from 001 to 999. Following number 999 the filters begin again with 001. (If a filter was exposed at a station other than the one for which it had been stamped, then the entire 8-digit number **must be** entered as the filter number).

**Batch Number** - This is the number which is stamped or written on the bottom left corner of the filter. These numbers vary in length and in characters which may be a combination of numbers and letters. Different batch numbers may be very similar, differing by only a single digit. The correct batch is required for proper laboratory analysis.

**Air Volume** - This is the calculated air volume.

**Product** - This box is for the requested test or test group. Air filters usually use Parent Products (Appendix D) which are group codes; each Parent Product contains one or more Products. A product(s) may be requested, in addition to, or deleted from, a parent product. PM10 samples have only one parent product which is the word QUARTZ. The Parent Product QUARTZ contains the Products for inhaleable particulate, one anion and nine metals. The Hi-vol parent product, HVD includes the products for TSP, three anions and eight metals.

TSPINV3288 is a product which is used instead of a parent product for all invalid samples, whether Hi-vol or PM10. This code allows the sample to be recorded in LIMS without any analyses being performed.

*Information placed in either of the following two areas will be typed into Laboratory Information Management System (LIMS) and should be legible. Comments typed elsewhere on the submission form will not be typed into LIMS. Comments relating to validity or to any unusual features of the sample should be entered for the benefit of both laboratory staff and Regional Analyst.*

**Field Staff Remarks** - This column is for short remarks. A remark which applies to consecutive samples may be placed in this column and dittoed down or arrowed down through those consecutive samples.

**Additional Comments** - This field, at the bottom of the page is for longer comments. Such comments may apply to one or more samples or to the entire submission.

**Field Staff Remarks, Check Filter - Yes**

A check mark should be placed on this line only if there is something wrong with the filter and the field technician does not know what to say about it in the way of remarks. A check mark on the line following the word "Yes", indicates that the particulate analyst should look at it before it is weighed. If a sample has been invalidated, there should be no need for it to be checked. If the field technician is not sure whether or not the sample should be invalidated, he or she should check the box to have the filter checked at the laboratory and include a note as to why. Please note: Laboratory staff do not invalidate samples without agreement from the regional office. They may, however, invalidate a filter for their particular test.

The air volume and product of the sample following an invalid filter must be properly coded.

When a station is terminated, it should be indicated in one of the comments sections.

**11 NO SAMPLE**

If there is no sample for a particular sampling date, it should be left on the submission form with the word INVALID in the air volume box and the code TSPINV3288 in the product box (see Section 9). If no filter was exposed, a line should be put through both the filter number and the batch number boxes.

**12 SUBMITTING SAMPLES**

The sample envelopes should be placed in chronological order. The submission sheet should be wrapped around them with the information visible (i.e. facing outward) and put into a corrugated box or padded envelope for shipping. Samples should be shipped flat or with the folded end of the filter in the down position, with the sample envelope facing left to prevent loss of particulates.

Samples are submitted to the laboratory on a monthly basis, within 30 days of the end of the month in which they were exposed.

If a Hi-vol station does not require TSP2009, then filters and submissions are submitted to LSB.

PM-10 filters and submission forms, and the original submission forms for Hi-vol filters are sent to:

Ministry of the Environment  
Laboratory Services Branch  
Physical Chemistry and Litigation Services Section  
Inorganic Air Unit  
125 Resources Road  
Etobicoke, ON M9P 3V6  
Attention: K. Burling

and copies of the Hi-vol submission forms are sent with the filters to:

Seprotech Laboratories  
2378 Holly Lane  
Ottawa, ON K1V 7P1  
Attention: D. Lambert

### 13 LIMS REMARK CODES AND VALUE QUALIFIERS

Below are lists of some of the LIMS remark codes and value qualifier codes that may appear on a final report.

#### 13.1 REMARK CODES ("Rmks" on final report):

EAC - equals or exceeds air guidelines  
EV - estimated value - tare weight unavailable  
PIE - possible improper exposure  
PFC - possible filter contamination  
PPL - possible particulate loss (Notes 1, 2)  
RRV - reported result verified by repeat analysis  
SVH - sample volume too high. Check hi-vol for leakage  
TEXT - textual information provided - see end of report  
TF - torn filter (Notes 1, 2)  
UCR - unreliable: could not confirm by reanalysis  
UCS - unreliable: contamination suspected  
UMF - unreliable: multiple filters submitted  
UNH - unreliable: sample not homogeneous  
UTF - unreliable: torn filter

#### 13.2 VALUE QUALIFIERS ("Qual" on final report):

> - actual result is greater than the reported value  
< - actual result is less than the reported value  
<T - a measurable trace amount: interpret with caution (Note 3)  
<W - no measurable response (zero): less than reported value (Note 4)  
NDAI - no data: additional information available  
NDAR - no data: see attached report  
NDAW - no data: analysis withdrawn  
NDCR - no data: could not perform confirming re-analysis

NDCS - no data: contamination suspected  
 NDIF - no data: invalid filter (no air volume) (Notes 5, 6)  
 NDIL - no data: sample incorrectly labeled  
 NDIV - no data: invalid sample (Notes 5, 6)  
 NDLA - sample spoiled in laboratory accident  
 NDMT - no data: sample missing in transit  
 NDND - no data: not analysed (not done)  
 NDNF - no data: information not received from submittor  
 NDNN - no data: tests requested in error  
 NDNR - no data: sample not received at laboratory  
 NDPM - no data: piece missing  
 NDRE - no data: sample received empty  
 NDRL - no data: see attached report from LWA Section  
 NDRN - no data: result forthcoming from radiation lab  
 NDRR - no data: rerun has been initiated  
 NDSM - no data: sample missing  
 NDST - no data: see attached textual information  
 NDTF - no data: torn filter  
 NDTW - no data: tare weight > loaded weight  
 NDUA - no data: sample unsuitable for analysis

Notes:

1. TF denotes a small tear (< 4 inches) in the exposed area.
2. TF & PPL denotes a tear ( $\geq 4$  inches) in the exposed area or a tear in the fold of a filter which contains loose particulate.
3.  $< 5 \mu\text{g}/\text{m}^3$  TSP, PM<sub>10</sub>.
4.  $< 1 \mu\text{g}/\text{m}^3$  TSP, PM<sub>10</sub>.
5. NDIF invalidates the sample for all tests. The product code TSPINV3288 is assigned for tracking purposes.
6. NDIV invalidates only the test(s) for which it is reported.

**Note:** Textual comments may be added in LIMS in addition to Remark Codes and Value Qualifiers.

Currently, only one LIMS code is printed beside the result on the final LIMS report. If more than one code is used, then the word TEXT will appear beside the result and the list of codes will be printed on the final page along with any textual comments.

If a result equals or exceeds the ambient air quality criterion, the code EAC will take precedence over TEXT.

## GLOSSARY

**ANION3004** - Analysed by ion chromatography.  
- Hi-vol (AG matrix) reports nitrate as nitrogen, chloride and sulphate.  
- PM10 (AQ matrix) reports only sulphate.

**EDXRF** - energy dispersive x-ray fluorescence.

**HIVOL3070** - analysed by energy dispersive x-ray fluorescence (AG matrix),  
( includes cadmium, chromium, copper, iron, lead, manganese, nickel and vanadium).

**IP3288** - Inhaleable particulate - quartz filters (analysis performed by the MOE laboratory).

**LSB** - Laboratory Services Branch.

**Matrix** - the medium from which a sample is taken, i.e. AG = glass-fibre filter, AQ = quartz-fibre filter.

**Parameter** - the actual analyte that is being tested (e.g. nickel) or a required piece of information about a particular sample (e.g. air volume).

**Parent Product** - a group of products with a common matrix that is used to speed up the logging in of multiple products for any given sample.

**PB3233** - lead analysed by wavelength dispersive x-ray fluorescence (AG matrix).

**Product** - specifies the actual analytical test or tests to be conducted via a given method within a specified matrix.

**RPL** - Radiation Protection Laboratory, Ministry of Labour.

**TSP2009** - Total Suspended Particulate - Hi-vol filters (analysis performed by a private laboratory).

**TSP3288** - Total Suspended Particulate - Hi-vol filters (analysis performed by the MOE laboratory).

**WDXRF** - wavelength dispersive x-ray fluorescence.

**XRF3277** - analysed by energy dispersive x-ray fluorescence (AQ matrix), (includes calcium, chromium, copper, iron, lead, manganese, nickel, vanadium and zinc).

**ZN3070** - zinc analyzed by energy dispersive x-ray fluorescence (AG matrix).

**CD3402** - cadmium analyzed by Inductively Coupled Plasma Mass Spectrometer (AQ Marix).

**APPENDIX A**  
**TYPES OF EXPOSED FILTERS**

Plate 1. Appropriate Sample

This is a properly exposed filter. It is pale because it is from the control site at Dorset. The Total Suspended Particulate is only  $5 \mu\text{g}/\text{m}^3$ .

Plate 1






Plate 2. Appropriate Sample

There is some seepage of particulate under the gasket but this affects neither TSP nor Inhaleable Particulate (IP). It may however, affect other analyses, so the word "seepage" is put in the comments area of the sample envelope to alert the analyst to be careful where he/she samples.




Plate 3. Appropriate Sample  
Rain spots.  
Rain markings appear pale on the particulate side of the filter.






Plate 4. Appropriate Sample

The same rain spots as in Plate 3 as seen on the unexposed surface of the filter.  
Rain markings appear darker on this surface.


Plate 4



14059252

Plate 5. Appropriate Sample

Wood fibre may appear as a yellowish particulate. This could be sample contamination or it could be the actual substance being monitored.





Plates. 6. Invalid Sample

Torn filter - pieces missing.

The filter tore during sampling. Note that the torn edge is darker than the rest of the exposed area of the filter.

Bird damage.

The loss of mass is estimated to be  $\geq 1 \text{ in}^2$  ( $2.5 \text{ cm}^2$ ) of filter.

LIMS code NDIF: (No data; invalid filter)

(If the sample had not been invalidated in the field, they would have been invalidated in the laboratory with LIMS code NDIV (No data; invalid sample) for each test(s) or

NDPM (No data; piece missing) for TSP.



Plates. 7. Invalid Sample

Torn filter - pieces missing.

The filter tore during sampling. Note that the torn edge is darker than the rest of the exposed area of the filter.

Bird damage.


The loss of mass is estimated to be  $\geq 1 \text{ in}^2$  ( $2.5 \text{ cm}^2$ ) of filter.

LIMS code NDIF: (No data; invalid filter)

(If the sample had not been invalidated in the field, they would have been invalidated in the laboratory with LIMS code NDIV (No data; invalid sample) for each test(s) or

NDPM (No data; piece missing) for TSP.

Plate 7



Plates. 8. Invalid Sample


The filters tore during sampling. Note that the torn edge is darker than the rest of the exposed area of the filter.

Bird damage.

The loss of mass is estimated to be  $\geq 1 \text{ in}^2$  ( $2.5 \text{ cm}^2$ ) of filter.

LIMS code NDIF: (No data; invalid filter)

(If the sample had not been invalidated in the field, they would have been invalidated in the laboratory with LIMS code NDIV (No data; invalid sample) for each test(s) or NDPM (No data; piece missing) for TSP.



A single line of faint, handwritten text spanning across the middle of the page. The script is cursive and difficult to decipher, but it seems to be a continuous sentence or a list of items.



Plate 9. Valid Sample - Possible Loss of Mass


Torn filter - piece missing.

LIMS codes TF (torn filter), PPL (possible particulate loss).

Loss of mass estimated to be  $< 1 \text{ in}^2$  ( $2.5 \text{ cm}^2$ ) of filter.


The white area in the torn edge indicates that the tear occurred after sampling with resulting particulate loss.

Torn-off pieces should be placed inside the folded filter, near the outer edge (on the margin, if possible), put into the sample envelope and submitted to the lab.





Plates. 10. Valid Sample - Possible Loss of Mass  
Torn filter.  
LIMS codes TF (torn filter), PPL (possible particulate loss).



Plates 11. Valid Sample - Possible Loss of Mass  
Torn filter.  
LIMS codes TF (torn filter), PPL (possible particulate loss).




Plate 12. Valid Sample - Possible Loss of Mass

Torn filter - margins.

The filter margins (bottom and right side) have been torn straight as if cut by a scalpel.

LIMS code TF (torn filter).






Plate 13. Valid Sample - Possible Loss of Mass

Torn filter - scrape.

This filter was torn after sampling. Note that the torn edge is white indicating particulate loss.

LIMS codes TF (torn filter), PPL (possible particulate loss).






Plate 14. Valid Sample - Possible Loss of Mass

Improper exposure in sampler.

A crease/wrinkle in the filter allowed air flow to leak under the gasket.

LIMS codes PIE (possible improper exposure), PPL (possible particulate loss).




Plate 15. Valid Sample - Possible Loss of Mass

Improper exposure.

An object such as a leaf stem or a wire lying across the margin of the filter, or a crack through the gasket could cause a leak.

LIMS codes PIE (possible improper exposure), PPL (possible particulate loss).




Plate 16. Valid Sample - Possible Loss of Mass

Improper exposure.

An improper gasket seal.

LIMS codes PIE (possible improper exposure), PPL (possible particulate loss).




Plate 17. Valid Sample - Possible Loss of Mass (in the sense of the particulate having been not collected in the first place)

Improper exposure.

The sample is too white. It appears unexposed. The particulate may or may not have come from a dirty gasket.






Plate 18. Valid Sample - Possible Gain of Mass  
Bird dropping.  
LIMS code PFC (possible filter contamination).

Plate 18



Plate 19. Valid Sample - Possible Gain of Mass

Bird dropping residue.

The same dropping as in Plate 18, as seen on the unexposed surface of the filter.

29114805



Plate 20. Valid Sample - Possible Gain of Mass  
Catkin fluff (edge-on view) (remove if possible).  
LIMS code PFC (possible filter contamination).



Plate 21. Valid Sample - Possible Gain of Mass  
Plant seed in bottom right corner (remove if possible).  
LIMS code PFC (possible filter contamination).

Plate 21






Plate 22 . Valid Sample - Possible Gain of Mass  
Moth (remove if possible).  
LIMS code PFC (possible filter contamination).




Plate 23. Valid Sample - Possible Gain of Mass  
Dark, 'oily' spots and pale spots may be insect or spider droppings.  
LIMS code PFC (possible filter contamination).





Plate 24. Valid Sample - Possible Gain of Mass  
Dirty filter holder  
Contamination of the unexposed margin from a dirty filter holder  
LIMS code PCF (possible filter contamination).



*Environment Ontario*  
Laboratory Library  
125 Resources Rd.  
Etobicoke, Ontario M9P 3V6  
Canada

Plate 25. Valid Sample - Possible Gain of Mass  
Possible contamination of the exposed surface from a dirty gasket.  
LIMS code PFC (possible filter contamination).






Plate 26. Valid Sample - Possible Loss and Gain of Mass  
Bird dropping - LIMS code PFC (possible filter contamination).  
Bird scratch marks - LIMS code PPL (possible particulate loss).




Plate 27. Valid Sample - Possible Loss and Gain of Mass  
Dark, 'oily' brown spots may be insect or spider droppings. LIMS code PFC (possible filter contamination).  
LIMS codes TF (torn filter), PPL (possible particulate loss).



Plate 28. Valid Sample - Possible Loss and Gain of Mass

Exterior view - The margin of the filter was covered with sand. It was embedded in the exterior (unexposed) surface. This was obvious contamination; there was nothing this large in the exposed area of the filter. LIMS code PFC (possible filter contamination)  
Removing the sand left holes in the filter. LIMS codes TF (torn filter).

29143284

## APPENDIX B

### Sample Envelopes

Figure 1

An invalid Hi-vol sample.

Figure 2

A valid PM10 sample.



STATION *17014*

HI-VOL No. .... DATE *14 NOV 2000*

FILTER No. *674* TYPE *H.G.* BATCH No. *7579*

OPERATOR ..... ON ..... OFF .....

FLOW READING ..... ON ..... OFF .....

COMMENTS *INVALID*

*Flow controller malfunction*

TOTAL VOLUME ..... CU. M.

WEIGHT ..... ON ..... OFF .....

WEIGHT DIFFERENCE .....

0887 (01/90)

FIGURE 1



STATION *12559* .....

HI-VOL No. .... DATE *14 OCT 2000* .....

FILTER No. *258344* / TYPE *Q4* ... BATCH No. *002283* .....

OPERATOR ..... ON ..... OFF .....

FLOW READING ..... ON ..... OFF .....

COMMENTS *Large brown stain in corner* .....

TOTAL VOLUME *1631* ..... CU. M.

WEIGHT ..... ON ..... OFF .....

WEIGHT DIFFERENCE .....

0887 (01-90)

FIGURE 2

## APPENDIX C

### SUBMISSION FORMS

#### INVALID SAMPLES

TSPINV3288 is the LIMS product code to use for all invalid samples.





















1. If a date is on the form for which a sample was not intended to be taken, the entire line pertaining to that sample is crossed off so a LIMS sample number will not be generated. (See Figure 1.)
2. If a sample was to be taken but for any reason was not, (no access to site, motor failure, incorrect filter type, etc.), the air volume is changed to INVALID and the product is changed to TSPINV3288, so a LIMS sample number can be generated and the sample information entered into LIMS. All other sample number information (batch number, filter number) is entered on the sheets as usual. (See Figure 1.)
3. If the same filter is exposed for two consecutive sampling days, the air volume and product are invalid for both days. (See Figure 1.)

#### NON-ROUTINE SUBMISSIONS

1. If a sample or set of samples must be submitted before the end of the month the submission sheet is to be photocopied and all sample information that does NOT apply to the filters being submitted, is to be crossed off. Repeat this procedure as often as required. (See Figure 2.)
2. If a current submission sheet is not available, that of another station may be photocopied. All information not applicable to the filters being submitted, (station id, program code, product, etc.) is to be crossed out and the correct information written in and submitted to the appropriate laboratory. (Figure 3.)

#### FILTER SUBSTITUTION

1. If a filter is used at a station, other than that designated by the laboratory, the station ID, batch number and filter number **MUST** be entered in the appropriate columns on the submission form. (See Figure 4.)
2. If a filter is used at a station other than that designated by the laboratory, the eight-digit station-filter ID number must be entered in the Filter Number column. The correct batch number must be entered in its column.

Submission Number		Client ID 21110 	Program Code 130113102    			Priority NN	Page 1
Prelog Number		Sample Location HAMILTON / Municipality				Date Submitted (DD-MMM-YYYY)	
Client Contact FRANK DOBROFF		Ministry / Branch / Office WEST CENTRAL HAMILTON P.O. BOX 2112 119 KING ST W., 12TH F		Telephone Number 905-521-7706 City / Town HAMILTON		Fax Number 905-521-7820 Postal Code L8P 4Y7	
Sampled By BILL SPARKS			Telephone Number 905-573-3693		Sample Reception / Data Entry		
Station ID 29118 		Matrix  AG					
Lab Sample Numbers		Sample Date (DD-MMM-YYYY)	Filter Number	Batch Number	Air Volume	Product	Remarks
Sample Number	MOE*LIMS	1-Mar-1999 			 1631	HVA 	Check Filter Yes --
Sample Number	MOE*LIMS	7-Mar-1999 	1	4848	 1631	HVA 	Check Filter NEW Yes -- STATION
Sample Number	MOE*LIMS	13-Mar-1999 	2	"	 1631	HVA 	Check Filter Yes --
Sample Number	MOE*LIMS	19-Mar-1999 	3	"	 1631 INVALID	HVA TSPINV3288 	Check Filter RAN Yes -- TWICE
Sample Number	MOE*LIMS	25-Mar-1999 	3	"	 1631 INVALID	HVA TSPINV3288 	Check Filter RAN Yes -- TWICE
Sample Number	MOE*LIMS	31-Mar-1999 	4	"	 1631	HVA 	Check Filter Yes --



















Additional Comments

Figure 1

Submission Number	Client ID 19189 	Program Code 130114102    		Priority NN	Page 1
	Sample Location / Municipality SOUTHWESTERN REGION			Date Submitted (DD-MMM-YYYY)	
Prelog Number					
Client Contact  DAN DOBRIN	Ministry / Branch / Office		Telephone Number	Fax Number	
	MINISTRY OF ENVIRONMENT 2nd Floor		519-873-5000	519-873-5020	
	661 Exeter Road, South		City / Town LONDON	Postal Code N6E 1L3	

Sampled By SCOTT KENNEDY	MIKE PARKER	Telephone Number 519-873-5046	Sample Reception / Data Entry
-----------------------------	-------------	----------------------------------	-------------------------------

Station ID 12507 	Matrix AQ 	
--	--	--





Lab Sample Numbers		Sample Date (DD-MMM-YYYY)	Filter Number	Batch Number	Air Volume	Product	Remarks
Sample Number	MOE*LIMS	1-Mar-1999 	853	7579	 1631	QUARTZ 	Check Filter Yes
Sample Number	MOE*LIMS	7-Mar-1999 	554	7579	 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	13-Mar-1999 			 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	19-Mar-1999 			 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	25-Mar-1999 			 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	31-Mar-1999 			 1631	QUARTZ 	Check Filter Yes



Additional Comments 7-MAR-1999 - PRIORITY POLLUTION INCIDENT



















MINISTRY OF ENVIRONMENT LABORATORY SERVICES BRANCH

MOE LIMS Sample Submission Form

Shaded Area Lab Use Only

Submission Number	Client ID 19189	Program Code 1301141023			Priority NN	Page 1
	   					
Prelog Number	Sample Location <del>ST-MARYS</del> / Municipality TECUMSEH				Date Submitted (DD-MMM-YYYY)	
Client Contact	Ministry / Branch / Office MINISTRY OF ENVIRONMENT 659 EXETER ROAD 2nd Floor			Telephone Number 519-873-5000		Fax Number 519-661-1742
DAN DOBRIN				City / Town LONDON		Postal Code N6E 1L3

















Sampled By MIKE PARKER		SCOTT KENNEDY	Telephone Number 519-873-504	Sample Reception / Data Entry	
Station ID 11001-12583	Matrix 				
		AG AQ			

Lab Sample Numbers		Sample Date (DD-MMM-YYYY)	Filter Number	Batch Number	Air Volume	Product	Remarks
Sample Number	MOE LIMS	5-Jul-1999 1 MAR 	253	74608	 1631	HVA QUARTZ 	Check Filter Yes -
Sample Number	MOE LIMS	11-Jul-1999 7 MAR 	254	"	 1631	HVA 	Check Filter Yes -
Sample Number	MOE LIMS	17-Jul-1999 13 MAR 	255	"	 1631	HVA 	Check Filter Yes -
Sample Number	MOE LIMS	23-Jul-1999 17 MAR 	256	"	 1631	HVA 	Check Filter Yes -
Sample Number	MOE LIMS	29-Jul-1999 25 MAR 	257	"	 1631	HVA 	Check Filter Yes -
Sample Number	MOE LIMS	N/A 31 MAR 	258	"	 N/A 1631	N/A ✓ 	Check Filter Yes -

Additional Comments

Figure 3



Submission Number	Client ID 54528 	Program Code 130115302    				Priority NN	Page 1
	Sample Location COPPER CLIFF WALDEN / Municipality					Date Submitted (DD-MMM-YYYY)	
Prelog Number							
Client Contact  DON RACETTE	Ministry / Branch / Office  MOE / NORTHERN REGION  435 JAMES STREET SOUTH				Telephone Number 807-475-1216		Fax Number 807-475-1754
					City / Town THUNDER BAY		Postal Code P7E 6S7
Sampled By WILFRED TREMBLAY		Telephone Number 705-564-3201		Sample Reception / Data Entry			
Station ID 77570 		Matrix AQ 					
Lab Sample Numbers		Sample Date (DD-MMM-YYYY)	Filter Number	Batch Number	Air Volume	Product	Remarks
Sample Number	MOE*LIMS	2-Dec-1999 	324	711862	 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	8-Dec-1999 	325	711862	 1631	QUARTZ 	Check Filter Yes ✓
Sample Number	MOE*LIMS	14-Dec-1999 	326	711280	 1631	QUARTZ -JP3298 	Check Filter Filter tore Yes -- Piece missing
Sample Number	MOE*LIMS	20-Dec-1999 	71368012	711862	 1631	QUARTZ 	Check Filter USED FILTER Yes -- FROM STATION 71368
Sample Number	MOE*LIMS	26-Dec-1999 	327	711280	 1631	QUARTZ 	Check Filter Yes --
Sample Number	MOE*LIMS	N/A 			 0	N/A 	Check Filter Yes --

Additional Comments

Figure 4

## APPENDIX D

**TABLE D-1**  
**LIMS PARENT PRODUCTS / PRODUCTS FOR HI-VOL FILTERS**

See glossary (page 13 ) for additional, explanatory remarks

* PARENT PRODUCT	Matrix	PRODUCT	DESCRIPTION	LIMS PRODUCT DESCRIPTION
HVA	AG	TSP2009 / TSP3288	TSP only	Particulate Loading
HVB	AG	TSP2009 PB3233	TSP Lead	Particulate Loading + Lead in Air Particulate
HVC	AG	TSP2009 HIVOL3070	TSP Metals	Particulate Loading + Metals in Air Particulate by XRF
HVD	AG	TSP2009 ANION3004 HIVOL3070	TSP Anions Metals	Particulate Loading + Anions in Air Particulate Glass Fibre + Metals in Air Particulate by XRF
HVE	AG	TSP2009 ANION3004 PB3233	TSP Anions Lead	Particulate Loading + Anions in Air Particulate Glass Fibre + Lead in Air Particulate
HVF	AG	TSP2009 ANION3004 PB3233 CARB3361	TSP Anions Lead Total & Free Carbons	Particulate Loading + Anions in Air Particulate Glass Fibre + Lead in Air Particulate + Total & Free Carbon in Air Particulate
HVG	AG	TSP2009 CARB3361 HIVOL3070	TSP Total & Free Carbons Metals	Particulate Loading + Total & Free Carbon in Air Particulate + Metals in Air Particulate by XRF
HVH	AG	TSP2009 CARB3361	TSP Total & Free Carbons	Particulate Loading + Total & Free Carbon in Air Particulate
HVM	AG	TSP2009 ID3092	TSP Ident.	Particulate Loading + Particulate Microscopy for Complaints
HVN	AG	TSP2009 ANION3004 RAD3167	TSP Anions Gross Beta	Particulate Loading + Anions in Air Particulate Glass Fibre + Gross Beta in Air Particulate - RPL
HVO	AG	TSP2009 ANION3004 PB3233 RAD3167	TSP Anions Lead Gross Beta	Particulate Loading + Anions in Air Particulate Glass Fibre + Lead in Air Particulate + Gross Beta in Air Particulate - RPL
HVQ	AG	TSP2009 RAD3167	TSP Gross Beta	Particulate Loading + Gross Beta in Air Particulate - RPL

**TABLE D-1**  
**LIMS PARENT PRODUCTS / PRODUCTS FOR HI-VOL FILTERS**

See glossary (page 13) for additional, explanatory remarks

* PARENT PRODUCT	Matrix	PRODUCT	DESCRIPTION	LIMS PRODUCT DESCRIPTION
HVS	AG	TSP2009 HIVOL3070 RAD3167	TSP Metals Gross Beta	Particulate Loading + Metals in Air Particulate by XRF + Gross Beta in Air Particulate - RPL
HVT	AG	TSP2009 ANION3004 CARB3361  HIVOL3070	TSP Anions Total & Free Carbons Metals	Particulate Loading + Anions in Air Particulate Glass Fibre + Total & Free Carbon in Air Particulate  + Metals in Air Particulate by XRF
HVV	AG	TSP2009 ANION3004 HIVOL3070 RAD3167	TSP Anions Metals Gross Beta	Particulate Loading + Anions in Air Particulate Glass Fibre + Metals in Air Particulate by XRF + Gross Beta in Air Particulate -RPL
HVW	AG	TSP2009 ANION3004	TSP Anions	Particulate Loading + Anions in Air Particulate Glass Fibre
HVY	AG	TSP3288 HIVOL3070 ZN3070	TSP ( <i>LSB</i> ) Metals Zinc	Particulate Loading + Metals in Air Particulate by XRF + Zinc in Hi-vol Filters

\* Commonly used Parent Products. Other Parent Products are available.

**TABLE D-2**  
**LIMS PARENT PRODUCT / PRODUCTS FOR PM-10 FILTERS**  
 See glossary (page 13) for additional, explanatory remarks.

PARENT PRODUCT	Matrix	PRODUCT	DESCRIPTION	LIMS PRODUCT DESCRIPTION
QUARTZ	AQ	IP3288 ANION3004 CD3402 XRF3277	PM10 SO <sub>4</sub> Cadmium XRF Metals	Particulate Loading - PM10 Filters + Anions in Air Particulate Glass Fibre + Cadmium in Air Filters + EDXRF Metals in Air Particulate -Quartz

**TABLE D-3**  
**LIMS PRODUCT FOR ALL INVALID AIR FILTERS**  
 See glossary (page 14) for additional, explanatory remarks.

PRODUCT	Matrix	DESCRIPTION	LIMS PRODUCT DESCRIPTION
TSPINV3288	AG / AQ	TSP / PM10 Invalid	Particulate Loading (TSP Invalid)





(6865)

MOE/GUI/AJGW

MOE/GUI/AJGW  
Burling, K  
A Guide to air  
filter (Hi-Vol and ajgw  
2000 c.1 a aa